



Viewing video stream using VLC player

1. Internal IP address of our camera: 172.16.26.11



2. RTSP Port: 4011



Example:

Command: `rtsp://IPaddress:RTSPport/stream#`

IP address: 172.16.26.14


RTSP port: 4014

Video Stream number/track: stream 1


Command: `rtsp://172.16.26.14:4014/stream1`

Steps:

1. When you open VLC Open Network Stream seek option in the menu tab Media.



2. In the new window put the RTSP command to display the video. If you want to display all camera streams only omit the part that selects the **/stream1**.



3. It will ask the credentials to access the camera and after providing them click OK and you should now be able to view the video stream from your camera.

